



03-030

FENDER FLARES

WILL FIT E-Z-GO® TXT®

INSTALLATION INSTRUCTIONS

INCLUDED:



Fender Flares



20 Push Rivets

Madjax® recommends professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves drilling holes into your bodywork. The Madjax® Limited Warranty only covers defects in materials and workmanship, and does not cover damage due to improper installation. If you are having difficulty installing this product, contact your Authorized Madjax® Dealer.

1

Test fit fender flare to bodywork to determine best placement. Holding the fender flare in place, mark locations to be drilled.



Drill first hole using a 9/32" drill bit. Ensure area behind body work is clear to avoid potential damage to wiring or other bodywork.

2

Insert barbed push rivet half-way to secure fender flare. Check other marked holes to ensure proper placement before drilling. Once sure of placement, rotate fender flare out of the way and drill other holes.



Push the first rivet in to secure fender flare and then insert other rivets.

Repeat Steps 1-4 for other three fender flares.



E-Z-GO®, E-Z-Go® TXT®, and E-Z-Go® RXV® are registered trademarks of Textron Innovations, Inc. ("Textron"). Reference to E-Z-Go®, TXT®, or RXV® or any of Textron's trademarks, word marks, or products is only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected to, affiliated with, sponsored by, or endorsed by Textron or any of its subsidiary companies.