



TRAILER HITCH
WILL FIT YAMAHA® DRIVE®
INSTALLATION INSTRUCTIONS
01-039

INCLUDED:

- TRAILER HITCH
- 2 M10X50 HEX HEAD BOLTS
- 4 M10 FLAT WASHERS
- 2 M10 LOCKING NUTS



1

Engage Parking Brake and chock wheels. Place RUN/TOW switch in TOW position. Using a 14mm socket remove factory bolts from bumper as shown. Retain hardware.



2

Remove factory bumper.

3
Mount hitch to center crossmember using supplied hardware.



4
Tighten bolts.

5
Reattach factory bumper using retained hardware from Step 1.



INSTALLATION COMPLETE

VISIT WWW.MYMADJAX.COM FOR MORE INSTALLATION VIDEOS.

Yamaha®, Yamaha® Drive®, G-14®, G-16®, G-19®, and G-22® are registered trademarks of Yamaha Golf-Car Company ("Yamaha"). Reference to Yamaha®, Yamaha® Drive®, any of the G-Series of Golf Carts, or any of Yamaha's trademarks, word marks, or products is only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected to, affiliated with, sponsored by, or endorsed by Yamaha or any of its parent or subsidiary companies.