



**LIGHT KIT
WILL FIT E-Z-GO® TXT®
INSTALLATION INSTRUCTIONS
MJLK2000**

INCLUDED:

- 2 Headlights
- 2 Tail Lights
- Wiring Harness
- Screws
- Straps
- Rocker Switch


TOOLS NEEDED:

- Phillips Head Screw Driver
- Cutting Tool
- Sandpaper
- Power Drill
- 15/32 Drill Bit



Madjax recommends professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves drilling holes into your cart's body.

Place template on front of the cart. Tape along the ridges in the cowl. Mark along the inside with a marking pen. *Flip template over for other side.



Drill pilot hole on the inside of the template line.




Cut out the shape of the headlight. *Use the cutting tool to remove the excess trim. Keep your template for the other side.



Use sandpaper to smooth the cut. Insert headlight and attach to cart using four of the screws provided. *Repeat process on other side.



*Make sure cart is in TOW mode. Feed front harness down through the front of the battery component. Run short tail light wire under the seat and over the tire well on the drivers side.



Choose 2 batteries side by side that are connected in series. Using a multimeter- probe ground to negative of one battery and probe positive from multi meter to positive of 2nd battery to check for 12 volts. This is where you will attach the positive & negative terminals from light kit.





Using the measurements provided on your tail light template, measure and mark your template. Use a marking pen to trace the inside line. *Flip template over to use on other side.



11

Feed the wire through the dashboard as shown.



Next drill a pilot hole so you will have a starting point and then begin cutting. *Use sandpaper to smooth edge.



Attach front headlights to wire harness. Secure excess wire with zip ties.

12



Attach rear tail light wire harness. Then place tail light into the rear of the vehicle. Insert four screws into tail light using supplied hardware. Secure wire with ties. *Repeat process on other side.

Using a 15/32" drill bit, drill out the hole for the rocker switch. *Drill gently.



Run the wire harness through the holes under the frame to secure the harness. *Use the zip ties provided.





Remove cup holder. Feed threaded end of switch through the dash where the hole was drilled. Retain hardware*

10

14

15

Earth - Ground (black)
Load - 12v(+) constant (red)
Supply - 12v(+) switched (blue)



16

Attach harness to rocker switch as shown.

17

Using retained hardware from Step 15, re-attach dashboard. Rocker switch should be installed as shown.



INSTALLATION COMPLETE

E-Z-GO®, E-Z-Go® TXT®, and E-Z-Go® RXV® are registered trademarks of Textron Innovations, Inc. Club Car®, Club Car® Precedent®, and Club Car® DS® are registered trademarks of Ingersoll Rand, Inc. Yamaha®, Yamaha® Drive®, G-14®, G-16®, G-19®, and G-22® are registered trademarks of Yamaha Golf-Car Company. Any reference to Club Car®, E-Z-Go®, or Yamaha® or their associated trademarks, word marks, and products are only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected to, affiliated with, sponsored by, or endorsed by either Textron Innovations, Inc., Ingersoll Rand, Inc., Yamaha Golf Cart Company, or any of their parent or subsidiary companies.



QUICK TIPS & TROUBLESHOOTING

Troubleshooting tips reflect common issues among all light kits. Some information stated below may regard to other Madjax Light kits. If you have more questions please contact customer service 866-410-5297.

The headlights won't stay adjusted?

Make sure the adjustment screw is tight and if it will not stay tight you can add a star washer to help hold it in place.

Everything is connected and nothing is working?

Make sure you are getting at least a full 12 volts at the light kit. Unplug each light to make sure it is not a short in one of the lights. Check the inline fuse connected to the positive battery post to make sure it is not blown.

PLEASE VISIT WWW.MYMADJAX.COM
FOR MORE INSTALLATION
VIDEOS AND SUPPORT

IF FURTHER TECHNICAL ASSISTANCE IS NEEDED PLEASE CALL CUSTOMER SERVICE 866-410-5297

BASIC HARNESS

BLACK = GROUND
 RED = 12V SWITCHED
 WHITE = 12V SWITCHED
 BLUE = 12V CONSTANT

